PACKAGING MACHINE OPERATING INSTRUCTIONS

- IF YOU ENCOUNTER A SITUATION NOT SHOWN IN TRAININGS, ALWAYS CONTACT THE AUTHORIZED COMPANY
- ADJUST THE MACHINE TO THE SIZE YOU WANT TO PACKAGE.
- PLACE THE PACKAGING MATERIAL (STRETCH FILM OR PAPER) INTO THE COMPARTMENT AND CLOSE THE LID.
- INSERT THE RAZOR WIRE COIL INTO THE HOUSING.
- ATTACH THE STRETCH FILM TO THE ROP AND SPIN IT TWICE IN JOG MODE.
- ADJUST THE SPEED SETTINGS AND THEN PRESS THE START BUTTON TO BEGIN THE PACKAGING PROCESS.
- YOU CAN ADJUST THE DESIRED INTENSITY DURING THE EXERCISE USING THE 1 SPEED SETTINGS.
- YOU CAN STOP THE MACHINE BY PRESSING THE STOP BUTTON WHEN THE PROCESS IS COMPLETE.
- NOTE: AFTER INSTALLING THE COIL, BE SURE TO ADJUST THE COIL SUPPORT ARMS TO APPLY GENTLE PRESSURE ON THE COIL.